


JM - BMT 90



Part No.	Thread		Dimension (mm)		
	E	F	A	B	S1
	JIC37	BSPT			
JM02-BMT02 90	5/16"-24	1/8"-28	20.5	21	11
JM04-BMT02 90	7/6"-20	1/8"-28	24.5	21	11
JM04-BMT04 90	7/16"-20	1/4"-19	26.6	25.5	14
JM04-BMT06 90	7/16"-20	3/8"-19	27.5	28	16
JM05-BMT02 90	1/2"-20	1/8"-28	26.6	23.5	14
JM05-BMT04 90	1/2"-20	1/4"-19	26.6	25.5	14
JM05-BMT06 90	1/2"-20	3/8"-19	27.5	28	16
JM06-BMT02 90	9/16"-18	1/8"-28	26.9	23.5	14
JM06-BMT04 90	9/16"-18	1/4"-19	26.9	25.5	14
JM06-BMT06 90	9/16"-18	3/8"-19	28.5	28.5	16
JM06-BMT08 90	9/16"-18	1/2"-14	32	36	22
JM08-BMT04 90	3/4"-16	1/4"-19	32	28	19
JM08-BMT06 90	3/4"-16	3/8"-19	32	30.5	19
JM08-BMT08 90	3/4"-16	1/2"-14	34.8	36	22
JM08-BMT12 90	3/4"-16	3/4"-14	37.9	43.5	27
JM10-BMT06 90	7/8"-14	3/8"-19	38	32	22
JM10-BMT08 90	7/8"-14	1/2"-14	37.8	36	22
JM10-BMT12 90	7/8"-14	3/4"-14	41	43.5	27
JM12-BMT08 90	1-1/16"-12	1"-22	44.2	40	27
JM12-BMT12 90	1-1/16"-12	3/4"-14	44.2	43.5	27
JM12-BMT16 90	1-1/16"-12	1"-11	47.8	50	33
JM16-BMT12 90	1-5/16"-12	3/4"-14	49	47.5	33
JM16-BMT16 90	1-5/16"-12	1"-11	49	50	33
JM16-BMT20 90	1-5/16"-12	1-1/4"-11	54	56.5	41
JM20-BMT16 90	1-5/8"-12	1"-11	55.5	56.5	41
JM20-BMT20 90	1-5/8"-12	1-1/4"-11	55.5	56.5	41
JM24-BMT20 90	1-7/8"-12	1-1/4"-11	62.5	61	48
JM24-BMT24 90	1-7/8"-12	1-1/2"-11	62.5	62.5	48
JM24-BMT32 90	1-7/8"-12	2"-11	74.5	67	63
JM32-BMT32 90	2-1/2"-12	2"-11	75.4	67	63