



JS - BMO

Part No.	Thread		Dimension (mm)				
	E	F	A	B	L	S1	S2
	BSPP	UNF/UN					
JS04-BMO04	1/4"-19	7/16"-20	10	9	26.5	19	15
JS05-BMO04	1/4"-19	1/2"-20	10	9	27.5	19	17
JS06-BMO04	1/4"-19	9/16"-18	10	10.5	27	19	19
JS06-BMO06	3/8"-19	9/16"-18	11.5	10.5	30.5	22	19
JS08-BMO06	3/8"-19	3/4"-16	11.5	10.5	32.5	22	24
JS08-BMO08	1/2"-14	3/4"-16	14	10.5	37.5	27	24
JS06-BMO08	1/2"-14	9/16"-18	14	10.5	35.5	27	19
JS10-BMO08	1/2"-14	7/8"-14	14	12	38	27	27
JS12-BMO12	3/4"-14	1-1/16"-12	15.5	15	39	32	32
JS08-BMO12	3/4"-14	3/4"-16	15.5	10.5	40	32	24
JS10-BMO12	3/4"-14	7/8"-14	15.5	11	40.5	32	27
JS16-BMO12	3/4"-14	1-5/16"-12	15.5	16	39	32	41
JS16-BMO16	1"-11	1-5/16"-12	18	16	46.5	41	41
JS20-BMO20	1-1/4"-11	1-5/8"-12	20	17	54.5	50	50
JS24-BMO24	1-1/2"-11	1-7/8"-12	21.5	20	57.5	55	55

THE
HYDRAULIC