



BM - BM - BM

Part No.	Thread			Dimension (mm)			
	E	F	G	A	B	C	S1
	BSPP	BSPP	BSPP				
BM02-BM02-BM02	1/8"-28	1/8"-28	1/8"-28	19.8	19.8	19.8	11
BM04-BM04-BM04	1/4"-19	1/4"-19	1/4"-19	24.5	24.5	24.5	14
BM04-BM06-BM04	1/4"-19	3/8"-19	1/4"-19	26.5	27.5	26.5	16
BM06-BM04-BM06	3/8"-19	1/4"-19	3/8"-19	27.5	26.5	27.5	16
BM06-BM06-BM06	3/8"-19	3/8"-19	3/8"-19	27.5	27.5	27.5	16
BM06-BM08-BM06	3/8"-19	1/2"-14	3/8"-19	31	34.5	31	22
BM08-BM06-BM08	1/2"-14	3/8"-19	1/2"-14	34.5	31	34.5	22
BM08-BM08-BM08	1/2"-14	1/2"-14	1/2"-14	34.5	34.5	34.5	22
BM10-BM10-BM10	5/8"-14	5/8"-14	5/8"-14	35	35	35	22
BM12-BM12-BM12	3/4"-14	3/4"-14	3/4"-14	40	40	40	27
BM12-BM16-BM12	3/4"-14	1"-11	3/4"-14	43.5	46	43.5	33
BM16-BM12-BM16	1"-11	3/4"-14	1"-11	46	43.5	46	33
BM16-BM16-BM16	1"-11	1"-11	1"-11	46	46	46	33
BM20-BM20-BM20	1-1/4"-11	1-1/4"-11	1-1/4"-11	50.5	50.5	50.5	41
BM24-BM24-BM24	1-1/2"-11	1-1/2"-11	1-1/2"-11	57.5	57.5	57.5	48
BM32-BM32-BM32	2"-11	2"-11	2"-11	72.5	72.5	72.5	63

THE
HYDRAULIC