



BM - BS - BM

| Part No. | Thread | | | Dimension (mm) | | | | |
|----------------|-----------|-----------|-----------|----------------|------|------|----|----|
| | E | F | G | A | B | C | S1 | S2 |
| | BSPP | BSPP | BSPP | | | | | |
| BM02-BS02-BM02 | 1/8"-28 | 1/8"-28 | 1/8"-28 | 19.8 | 5.5 | 19.8 | 11 | 14 |
| BM04-BS04-BM04 | 1/4"-19 | 1/4"-19 | 1/4"-19 | 24.5 | 5.5 | 24.5 | 14 | 19 |
| BM06-BS06-BM06 | 3/8"-19 | 3/8"-19 | 3/8"-19 | 27.5 | 6.3 | 27.5 | 16 | 22 |
| BM08-BS08-BM08 | 1/2"-14 | 1/2"-14 | 1/2"-14 | 34.5 | 7.5 | 34.5 | 22 | 27 |
| BM12-BS12-BM12 | 3/4"-14 | 3/4"-14 | 3/4"-14 | 40 | 10.9 | 40 | 27 | 32 |
| BM16-BS16-BM16 | 1"-11 | 1"-11 | 1"-11 | 46 | 11.7 | 46 | 33 | 41 |
| BM20-BS20-BM20 | 1-1/4"-11 | 1-1/4"-11 | 1-1/4"-11 | 50.5 | 11 | 50.5 | 41 | 50 |
| BM24-BS24-BM24 | 1-1/2"-11 | 1-1/2"-11 | 1-1/2"-11 | 57.5 | 13 | 57.5 | 48 | 55 |
| BM32-BS32-BM32 | 2"-11 | 2"-11 | 2"-11 | 72.5 | 16 | 72.5 | 63 | 70 |

THE
HYDRAULIC