



BMT - BNT 90

Part No.	Thread		Dimension (mm)		
	E	F	A	B	S1
	BSPT	BSPT			
BMT02-BNT02 90	1/8"-28	1/8"-28	24.5	23	16
BMT04-BNT04 90	1/4"-19	1/4"-19	28.5	25	19
BMT06-BNT06 90	3/8"-19	3/8"-19	33.5	25	24
BMT08-BNT08 90	1/2"-14	1/2"-14	40.8	31.5	30
BMT12-BNT12 90	3/4"-14	3/4"-14	47.5	37	33
BMT16-BNT16 90	1"-11	1"-11	56.5	43	41
BMT20-BNT20 90	1-1/4"-11	1-1/4"-11	61	50	48
BMT24-BNT24 90	1-1/2"-11	1-1/2"-11	75	55	63

THE
HYDRAULIC