



BS - BM - BM

Part No.	Thread			Dimension (mm)				
	E	F	G	A	B	C	S1	S2
	BSPP	BSPP	BSPP					
BS02-BM02-BM02	1/8"-28	1/8"-28	1/8"-28	19.8	19.8	5.5	11	14
BS04-BM04-BM04	1/4"-19	1/4"-19	1/4"-19	25	25	5.5	14	19
BS06-BM06-BM06	3/8"-19	3/8"-19	3/8"-19	27.5	27.5	6.3	16	22
BS08-BM08-BM08	1/2"-14	1/2"-14	1/2"-14	34.5	34.5	7.5	22	27
BS10-BM10-BM10	5/8"-14	5/8"-14	5/8"-14	34.5	34.5	9.5	22	30
BS12-BM12-BM12	3/4"-14	3/4"-14	3/4"-14	40	40	10.9	27	32
BS16-BM16-BM16	1"-11	1"-11	1"-11	46	46	11.7	33	41
BS20-BM20-BM20	1-1/4"-11	1-1/4"-11	1-1/4"-11	50.5	50.5	11	41	50
BS24-BM24-BM24	1-1/2"-11	1-1/2"-11	1-1/2"-11	57.5	57.5	13	48	55
BS32-BM32-BM32	2"-11	2"-11	2"-11	72.5	72.5	16	63	70

THE
HYDRAULIC