


# BS - BMT 90



Part No.	Thread		Dimension (mm)			
	E	F	A	B	S1	S2
	BSPT	BSPP				
BS02-BMT02 90	1/8"-28	1/8"-28	21	5.5	11	14
BS04-BMT04 90	1/4"-19	1/4"-19	25.5	5.5	14	19
BS06-BMT06 90	3/8"-19	3/8"-19	28.5	6.3	16	22
BS08-BMT06 90	3/8"-19	1/2"-14	31	7.5	19	27
BS06-BMT08 90	1/2"-14	3/8"-19	36	6.3	22	22
BS08-BMT08 90	1/2"-14	1/2"-19	36	7.5	22	27
BS12-BMT08 90	1/2"-14	3/4"-14	37	10.9	24	32
BS08-BMT12 90	3/4"-14	1/2"-19	43.5	7.5	27	27
BS12-BMT12 90	3/4"-14	3/4"-14	43.5	10.9	27	32
BS16-BMT16 90	1"-11	1"-11	50	11.7	33	41
BS20-BMT20 90	1-1/4"-11	1-1/4"-11	58	11	41	50
BS24-BMT24 90	1-1/2"-11	1-1/2"-11	62.5	13	48	55

THE  
HYDRAULIC